

Step by Step Deployment Procedure – Commander 3400

Step 1: Use heavy-duty wheel jack to unhitch from tow vehicle

- Latching pin
- Safety chains
- 7-way harness
- Emergency brake

Step 2: Use front wheel jack to try and get the trailer as level as possible (be aware of surroundings)

Step 3: Deploy all (4) Outrigger Jacks – crank handles until you feel tension

Step 4: Power on the PCM – Toggle Switch Up

Step 5: Put the Generator in Monitoring Voltage – Toggle Switch Middle

Step 6: Take cameras out of the Camera Storage Rack and Connec Cables from Storage Bin

Step 7: Install Cameras (tighten with Lock Nut) and Cables to their identified/labeled mounting locations on the mast (Cam1, Cam2, Cam3, Cam4) – aim the Cam Mounts/Eth Bulkheads towards the Top Mast Box (takes roughly 5min for cameras to power on)

Step 8: Login to the Laptop and open the VMS Software to view Cameras before raising the Mast (or VMS from a Cloud based platform)

Step 9: Remove the Safety Pin on the Mast

Step 10: Tilt then Extend the Mast

Step 11: Check VMS on the Laptop again (or VMS from a Cloud based platform)

Step 12: Deploy Solar Pannels (if installed)

Step 13: Turn Generator Toggle Switch to Monitoring Voltage (middle)

Step 14: Lock up all the Doors

Step 15: Lock up the Tongue or remove the Tongue assembly